



INSTRUCTIONS FOR INSTALLING VALVE REBUILDING KIT ON PROTEX II® CYLINDER VALVES

CAUTION

BEFORE REMOVING AND DISASSEMBLING VALVE, MAKE CERTAIN THERE IS NO PRESSURE IN THE CYLINDER. IF CYLINDER CONTAINS PRESSURE, SERIOUS INJURY COULD OCCUR.

DISASSEMBLY

- 1. Remove valve cap assembly from top of valve.
- 2. Using a 1/4 in. bolt, screw bolt into top of piston and pull up to remove piston.
- 3. Remove siphon tube.
- Remove all components from valve cavity; spring, and valve stem assembly.
- 5. Carefully clean all interior surfaces of the valve. Make certain no scratching of internal surface occurs.
- 6. Remove O-ring from piston and valve collar.
- 7. Discard all old O-rings and internal valve components.

ASSEMBLY


Prior to assembly, lubricate new piston, valve stem assembly and collar O-rings with O-ring lubricant.

Make certain all components and the interior of the valve body are clean and free of oil.

- Push the valve stem assembly into the valve body from the bottom side.
- Position spring over top of valve stem assembly.
 Note: Make certain small coil end of spring faces top of valve.
- Install new Valve O-ring on piston and install piston back into valve body. Remove 1/4 in. bolt used previously to pull out piston.
- 4. Reinstall valve cap assembly.
- 5. Install new O-ring on cylinder valve collar threads.
- 6. Reinstall siphon tube.
- 7. Valve rebuilding procedure is now complete.


Copyright © 2023 Heiser Logistics. All rights reserved.

ProTex II*, and the product names listed in this material are marks and/or registered marks. Unauthorized use is strictly prohibited.



Valve Assembly Cross Section (Part No. 551175)

	P/N	Description
1	N/A	Valve Body
2	N/A	Valve Stem Assembly
3	385420705	Valve Spring
4	712420707	Piston
5	325420716	Valve O-Ring
6	551236	Pressure Gauge
7	490020831	Valve Cap Assembly
8	325420714	Valve Cap O-Ring
9	325420715	Piston O-Ring
10	550985	Pressure Regulator



Valve Rebuilding Kit (Part No. 490420698)

	P/N	Description
1	N/A	Valve Stem Assembly
2	385420705	Valve Spring
3	325420716	Valve O-Ring
4	325420715	Piston O-Ring